HT-4139 Image Scanner Driver

Installation Guide

HITACHI

Notes

- It is strictly prohibited to reprint or copy part or all of this manual without our permission.
- The content of this manual is subject to change without prior notice due to improvement.

It becomes a screen in English version Windows in the text.

Indication of non-Hitachi trademarks

Windows XP, Windows Vista,Windows7 are registered trademarks of Microsoft Corporation in the United States and other countries.

Feb 2008	(First edition)
Aug 2009	HT-4134 connected with same PC
JAN 2009	For Windows7
Mar 2010	For 01-02-/A

Contents

Notes 2

1. System Requirement 4

When you install it in Windows(R) XP 6

When you install it in Windows(R) Vista 7

When you install it in Windows(R) 7 9

2. How to install 11

2.1 about README.TXT 11

2.2 How to install 13

When you install it in Windows(R) XP 13

When you install it in Windows(R) Vista 13

When you install it in Windows(R) 7 14

2.3 Installation screen 15

2.4 Note 18

3. Scanner driver installation 19

3.1 When you install it in Windows(R) XP 19

3.2 When you install it in Windows(R) Vista 22

3.3 When you install it in Windows(R) 7 29

4. How to uninstall / repair program 36

4.1 Repair program 36

4.1 Uninstall program 37

1. System Requirement

This software is required following environments.

1) Operating System

Microsoft(R) Windows(R) XP Professional SP2(English)

Microsoft(R) Windows(R) XP Professional SP2(Chinese)

Microsoft(R) Windows(R) Vista Bussiness SP1(English)

Microsoft(R) Windows(R) Vista Bussiness SP1(Chinese)

Microsoft(R) Windows(R) 7 Professional (English)

Microsoft(R) Windows(R) 7 Professional (Chinese)

2) About the installation destination

The installation destination is always C:\OCR32.

It is not possible to install it in the environment

that cannot be copied onto C drive.

There is a possibility that the application cannot be correctly used

when the directory is using it by another application.

3) Notes when HT-4134 Image scanner Driver is installed.


"P-242H-J5KJ4 HT-4134 Image Scanner Driver" and

"P-242H-J5KJ9 HT-4139 Image Scanner Driver" must use the same version.

When the system with a different version is installed, it is not possible to operate correctly.

Confirm method of version

Please refer to Readme.txt in installation CD for the version of HT-4139 Image Scanner driver.



The version is a format of Ver major version- minor.version- revision.


Please compare it by the following values when there is Revision.

Ver of ReadMe.txt	Version
Ver 01-02-/A	1.2.1


Confirm method of version of installed HT-4134 ImageScanner Driver

When you install it in Windows(R) XP

Please start the Add or Remove Programs from the Control Panel.



Please click “Click here for support information” of HT-4134 Image Scanner Driver.




Please confirm Version.

The version is a format of major version .minor.version .revision.


Please compare major version , minor version and revision.

When you install it in Windows(R) Vista

Please start the Programs from the Control Panel.



Click Programs.- Programs and Features.




Please confirm Version.

The version is a format of major version .minor.version .revision.


Please compare major version .minor.version .revision.

Please Click [Organize]- [Layout]-[DetailsPane] when Details Pane is not displayed.




When you install it in Windows(R) 7

Please start the Programs from the Control Panel.



Click Programs.- Programs and Features.




Please confirm Version.

The version is a format of major version .minor.version .revision.

Please compare major version and minor version.

Please Click [Organize]- [Layout]-[DetailsPane] when Details Pane is not displayed.



2. How to install

Be sure to log on as a user with administrator privileges to install the program.

Please do not connect the HT-4139 scanner yet.


2.1 about README.TXT

Insert the installation CD into the CD-ROM drive.


When CD is put, the content of README.TXT in CD is displayed by the automatic operation.

Please install it after confirming the content.

(Please display the content of README.TXT with the note pad etc. when not starting automatically.)




The following screen might be displayed for Windows VISTA.



Please click "Run Notepad.exe" to continue.

The following screen might be displayed for Windows 7.




Please click "Run Notepad.exe" to continue.

2.2 How to install


When you install it in Windows(R) XP

1)In the root directory, double-click SETUP.MSI.



When you install it in Windows(R) Vista

1) In the root directory, right-click Setup.EXE.




2) Select 'Run as administrator' from the context menu.

The message of "An unidentified program wants access to your computer" might be displayed by User account Control.

Please click " Allow" to continue.

When you install it in Windows(R) 7

1) In the root directory, right-click Setup.EXE.



2) Select 'Run as administrator' from the context menu.


The message of " Do you want to allow the following program from an unknown publisher to make changes to this computer?" might be displayed by User account Control.

Please click " Yes" to continue.

2.3 Installation screen


1）Start preparation screen

The Start preparation screen is displayed during the preparation for the installation.




It automatically changes to the installation start screen when it is possible to prepare it.

2)Installation start screen




Please click "Next" to continue.

3）License Agreement screen




Please move the scrollbar, read the text to the last minute, and confirm it.



If you accept the terms below,click "I Agree",then "Next".


Otherwise click "Cancel".

4)Screen under installation



It automatically changes to the installation end screen when the installation ends.

5)Installation end screen



Please click "Close" to end.

Please take out installation CD.

2.4 Note

Please reboot PC so that the installation may become effective.

Please uninstall it previously when you reinstall it.

It is likely not to be installed correctly when not uninstalling it.

Notes when HT-4134 Image Scanner Driver is installed.

When failing in the installation of HT-4139 Image Scanner Driver,

Or When HT-4139 Image Scanner Driver is uninstalled,

It becomes impossible for the software of HT-4134 Image Scanner Driver

to work correctly.

Please install HT-4134 Image Scanner Driver again.

---

3. Scanner driver installation


3.1 When you install it in Windows(R) XP

Please connect the HT-4139 scanner and turn on the power supply.


Found New Hardware wizard is displayed.




Please select “No, not this time” and click “Next”.(This dialog might not be displayed.)




Please select " Install the software automatically[Recommended]" and click "Next".



Please select "HT-4139 OCR Image Scanner(Location is ht-4139.inf.)" and click "Next".



Please click "Continue Anyway" to continue.




Please click "Finish" to Finish.

3.2 When you install it in Windows(R) Vista

Please connect the HT-4139 scanner and turn on the power supply.


Found New Hardware is displayed.




Please click "Ask me again later" to end “Found New Hardware”.

Please start the Device Manager from the Control Panel.


Open Device Manager by clicking the **Start** button, clicking **Control Panel**, clicking **System and Maintenance**, and then clicking **Device Manager**.






If you are prompted for an administrator password or confirmation, type the password or provide confirmation.

The message of "Windows needs your permission to continue" might be displayed by User account Control.




Please select "HT-4139 OCR Image Scanner" from “Other devices",and right-click


Select “Properties“ from the context menu.




Please click "Reinstall Driver " to continue.




Please click " Browse my computer for driver software " to continue.




Please click " Let me pick from a list of device drivers on my computer " to continue.




Please select "Imaging devices "from Common hardware type and click "Next".



Please click "Next" to continue.



Please click "Install this driver software anyway " to continue.




Please click "Close" to end.


3.3 When you install it in Windows(R) 7

You must be logged on as an administrator to perform these steps.

Please connect the HT-4139 scanner and turn on the power supply.


Found New Hardware is displayed.







Please start the Device Manager from the Control Panel.

Open Device Manager by clicking the **Start** button, clicking **Control Panel**, clicking **Hardware and Sound**, and then clicking **Device Manager**. If you are prompted for an administrator password or confirmation, type the password or provide confirmation.









Please select "HT-4139 OCR Image Scanner" from “Other devices",and right-click


Select “Properties“ from the context menu.




Please click "Update Driver " to continue.




Please click " Browse my computer for driver software " to continue.




Please click " Let me pick from a list of device drivers on my computer " to continue.




Please select "Imaging devices "from Common hardware type and click "Next".



Please click "Next" to continue.



Please click "Install this driver software anyway " to continue.




Please click "Close" to end.

4. How to uninstall / repair program

The installer is started as well as a new installation.


(Refer to ”2.How to install”.)

4.1 Repair program




Please select "Repair HT-4139 Image Scanner Driver".

Please click "Finish" to continue.




Please click "Close" to end.

4.1 Uninstall program



Please select "Remove HT-4139 Image Scanner Driver".

Please click "Finish" to continue.



Please click "Close" to end.